



Step 1

King Dimensions Antler Mounting Kit Instructions

Congratulations on your trophy and thank you for choosing King Dimensions Trophy products. We encourage you to read through all the instructions carefully prior to beginning the process so you have an overall understanding before you begin. Take your time and enjoy the experience!



Step 2

Step 1: Remove the antlers from your deer, remove all hair and tissue from the skull. You can rub borax preservative or salt/baking soda mix on the skull to speed drying of the remaining tissue. Cut the remaining skull base to fit within the pre-drilled hole locations on the plaque from top to bottom. On a very large skull base, you may need to trim the sides of the base as well so as to not interfere with the antler cover supplied in your kit.



Step 3

IMPORTANT Every skull base is unique, and you may need to adjust the height and angle of your antler base by cutting more from the back, or if you need additional height, by adding layers of cardboard or other shim stock to the underside of the base.



Step 4

Step 2: Using the two plastic hose clamps supplied, from the visual side of the plaque, thread one through the top left predrilled hole, and one through the top right predrilled hole. Continue to thread from the underside of the plaque into the corresponding bottom hole. You will be able to bend the plastic clamp on the backside to fit snugly to the plaque. The actual screw/clamp mechanism should be at the bottom of the skull base so as not to interfere with the antler cover provided. (Note: A small amount of moisture has been added to the sealed hose clamp bag to assure maximum strength of the nylon clamping system)



Step 5

Step 3: Position the antler base between the predrilled holes from top to bottom. Without the clamp screw in position, place the leading end of the clamp into the clamp slot and pull slack tight. Place the clamp screw into the hole and using the hex tool supplied, tighten the clamp. Again, make sure the height and angle are right for the antler cover supplied.

Step 4: Trim the excess clamp length away to clear the antler cover.

Step 5: Antlers should now sit squarely in position.



Step 6

Step 6: Using a small, sharp scissors, cut a small slit and opening into the antler cover. Carefully trim the hole to fit your specific antler base on each side. Continue to fit the cover until it fits over the antler base, trimming small amounts at a time so as not to cut too large an opening. Be patient on this step as this is where the final appearance is determined.

If you need to adjust the height of the skull base to help the overall fit, remove the clamps and adjust the height accordingly.



Step 7

After you're satisfied with the fit of the antler cover, fasten into its final position using the two decorative tacks supplied. We recommend that you use a starter hole with a small nail or awl as the wood is hardwood. When hammering the tacks into position, use the wooden dowel as a buffer between the hammer and the head of the tack. Your antler cover should now be secured to its final position.

Step 7: Screw the hanger on the back of the panel (screw and hanger included) and proudly display your mount.